


GorillaConcreteTools

GS-300 Early Entry

Product Manual




Parts Diagram




Part Number	Description
GS300 - 1	Saw Base
GS300 - 2	Front Wheel Mount
GS300 - 3	4" Wheel
GS300 - 4	Motor Plate
GS300 - 5	Motor Plate Bearing
GS300 - 6	Shaft Bearing
GS300 - 7	Blade Shaft
GS300 - 8	Blade Shaft Spacer
GS300 - 9	Blade Shaft Key
GS300 - 10	Sheave Bushing
GS300 - 11	Blade Shaft Sheave
GS300 - 12	Drive Belt

GS300 - 13	Engine
GS300 - 14	Drive Sheave
GS300 - 15	Alternator mounting Plate
GS300 - 16	Alternator
GS300 - 17	Alternator Drive Belt (Not Pictured)
GS300 - 18	Belt Guard
GS300 - 19	Lift/Lower Handle
GS300 - 20	Depth Stop Backer Plate
GS300 - 21	Depth Stop
GS300 - 22	Blade Clamp
GS300 - 23	Blade Shaft Nut
GS300 - 24	Engine Shaft Key (Not Pictured)



Part Number	Description
GS300 - 26	Handle Upright
GS300 - 27	Lift Handle Lock
GS300 - 28	Wrench Holder
GS300 - 29	Handle
GS300 - 30	Handle Grip
GS300 - 31	Electronics Mount
GS300 - 32	Thumb Switch Mount
GS300 - 33	Thumb Switch (sold individually)
GS300 - 34	Controller
GS300 - 35	Potentiometer
GS300 - 36	Reverse Switch


GS300 - 37	On/Off Switch
GS300 - 38	Electronics Cover
GS300 - 39	Shaft Wrench
GS300 - 40	Blade Shaft Nut Wrench
GS300 - 41	Upper Linkage Arm
GS300 - 42	Linkage Block
GS300 - 43	Lower Linkage arm
GS300 - 44	Pointer Arm



Part Number	Description
GS300 - 49	Electric Drive Motor Plate
GS300 - 50	Wheel Shaft
GS300 - 51	Wheel Shaft Sprocket
GS300 - 52	Wheel Shaft Bearing
GS300 - 53	Drive Motor
GS300 - 54	Drive Pulley
GS300 - 55	Drive Chain
GS300 - 56	Chain Cover
GS300 - 57	Foot Peg
GS300 - 58	Wheel Hub

GS300 - 59	8" Wheel
GS300 - 60	Shaft Collar
GS300 - 61	Motor Cover
GS300 - 62	Battery Tray
GS300 - 63	Battery
GS300 - 64	Battery Cover
GS300 - 65	Battery Cover Mount

GS-300 Early Entry Dust Box



Part Number	Description
GS300 - 70	Dust Box
GS300 - 71	Tensioner Slide Mount
GS300 - 72	Tensioner Slide
GS300 - 73	Skid Plate Tensioning Spring
GS300 - 74	Skid Plate Tensioner
GS300 - 75	Dust Box Internal Baffle
GS300 - 76	Internal Baffle Plate
GS300 - 77	Dust Box Door Baffle
GS300 - 78	Door Baffle Plate
GS300 - 79	Dust Box Door
GS300 - 80	Dust Port
GS300 - 81	Skid Plate
GS300 - 82	4-arm Knob
GS300 - 83	Dust Port Block Off Plate (Not Pictured)
GS300 - 84	Complete Dust Box Assembly